

TO FIT SIZE CHART

Measurements refer to body size, not garment dimensions



S171M - SPRINT PANT

25.02.2016

	S	M	L	XL
Waist in inches*	32	34	36	38
Waist in cm*	81	86	91	96

HOW TO MEASURE CHEST: Place the tape measure across the back, underneath the arms and then across the fullest part of the chest.

1 Inch = 2,54 cm